Lake Lucille and Big Lake Water Quality Monitoring Big Lake Final Sampling Plan

May 7, 2004

Prepared for:

Alaska Department of Environmental Conservation 555 Cordova Street Anchorage, AK 99501

Prepared by:

OASIS Environmental, Inc. 807 G Street, Suite 250 Anchorage, AK 99501

Table of Contents

1	Intro	duction	1
2 Sampling Design			
		Schedule	
		Site Selection	
3	Meth	nods	1
	3.1	Analytical Sample Collection	1
	3.2	Field Parameters	1

Attachment A. USGS Open-File Report 97-401 VOC Sampler

1 Introduction

Big Lake is targeted under the Alaska Clean Water Actions program as a priority waterbody for water quality. High recreational use and a developed shoreline with little regulation are possible sources impacting water quality. Depressed dissolved oxygen levels have been reported seasonally during thermal stratification in the summer and ice cover in the winter. Nutrient loadings during the summertime increase production and decrease dissolved oxygen levels. Possible nutrient sources include lawn fertilizers, septic systems, outhouses and animal waste.

The 2004 water quality monitoring at Big Lake is being performed for the Alaska Department of Environmental Conservation (ADEC). Parameters that will be included in the monitoring are nutrients, dissolved oxygen, bacteria and hydrocarbons. Anthropogenic sources of bacteria include human and animal waste and septic systems. Possible hydrocarbon inputs to Big Lake include boat, plane and small motorcraft traffic and maintenance and fueling areas.

2 Sampling Design

2.1 Schedule

Samples will be collected at Big Lake during three sampling events: two in May and one in June. The first sampling event will be on May 15 and 16 if the ice has melted and a boat can be launched to access the sampling sites. This sampling event is scheduled to occur before spring turnover; an event caused by the upper water layer warming to 39° F (maximum density), sinking and mixing the water column. The first sampling event will provide a baseline for comparing with results from later in the summer when recreational usage increases. The second sampling event will be conducted on May 29 and 30 to target high recreational use over Labor Day weekend. The final sampling event will be conducted on June 12 and 13. The sampling events are scheduled on weekends in order to target the highest number of recreational users on the lake. Motorboat samples will be collected at all of the sampling sites on Big Lake on Saturday evenings, when motorized recreation is expected to be highest. Nutrient and bacteria samples will be collected on Sundays.

2.2 Site Selection

Sampling sites on Big Lake will be selected for each group of parameters: nutrients, bacteria and hydrocarbons. Some of the sites may be used to sample for more than one group of parameters. Where possible sources of contamination for all three groups of parameters are present, such as a subdivision with high motorcraft traffic, all parameters may be collected at the same site. Due to site selection overlap, approximately eighteen total sample sites are estimated. The sampling sites will include background sites and additional sites selected based on the locations of possible sources contributing to each group of parameters. Historic sampling sites and sites with possible receptor organisms (swimming beaches, sensitive habitat areas, etc.) will also be considered when selecting the sampling locations. Maps of the proposed locations of the sampling sites are

included as figures in the Quality Assurance Project Plan (QAPP) and descriptions of the sampling sites are in Table 2 of the QAPP.¹

Nutrient sampling sites will be located close to areas of high density housing where inputs such as fertilizers, septic systems, outhouses, pet waste, etc. could contribute to nutrient loading. Samples will be collected from each of six sites at a depth of 1 meter and 75% of the total depth for nutrient analyses.

Bacteria samples will also target areas of high density housing where septic systems, outhouses, pets, etc. could increase bacterial concentrations. Fourteen sampling sites will be selected for bacteria sample collection based on possible sources at the lake. Six of the sampling sites will be located near to swimming areas in order to determine if there is human exposure to bacteria. Two of the fourteen sites will be determined during the first sampling event in May based on use observations at the lake. Two types of bacteria analyses will be performed on samples collected at Big Lake, fecal coliform and E. coli. At each sampling site, one E. coli sample will be collected and three fecal coliform samples will be collected within a 50 meter radius. Two additional E. coli samples will be collected at each of the six swimming areas.

Hydrocarbon sampling sites will be located in places where boat, plane or small watercraft traffic is estimated to be highest. Possible sources that will affect motorcraft traffic include boat launches, traffic lanes, maintenance and fueling areas, and sections of the lake with high dock density. Hydrocarbon samples will be collected at four depths at four of the sample sites: 15 cm, 45 cm, 1.5 meters and 5 meters. At an additional ten hydrocarbon sampling sites, one sample will be collected at 45 cm for a total of fourteen sampling sites. Two of the fourteen sites selected near to possible sources will be determined during the first sampling event in May based on use observations at the lake. Area residents familiar with lake activity will be interviewed to identify potential sample

sites. A map of the selected sample sites will be provided in the final sampling plan.

3 Methods

A small (15') aluminum skiff with a 25 hp outboard motor will be launched at the Berkshore marine on the east end of Big Lake. A handheld Garmin GPS unit will be used to record the sampling locations during the first sampling event in May and to locate the sampling locations during subsequent sampling events. The motor will be turned off upon reaching the sample site and, if necessary, an anchor will be dropped to keep the boat at the sample site. Samplers will wear nitrile gloves at all times during sampling and new gloves will be used for collecting each set of samples. Observations and photographs will be taken at each sampling location and recorded in a field notebook. Observations will include algal presence on the lake surface, motorboat, plane and small motorcraft traffic near to the sampling site, wind direction and speed, surface sheen and weather conditions.

3.1 Analytical Sample Collection

Analytical samples will be collected using a VOC sampler for hydrocarbons and a Kemmerer water sampling bottle for other parameters. Wildco® constructed a sampler designed by the USGS for collecting VOC samples specifically from surface waters. The VOC sampler is designed to collect samples at depth without any loss to volatilization.

¹ OASIS Environmental, Inc., Quality Assurance Project Plan Revision 2.0, prepared for Alaska Department of Environmental Conservation, May 2004.

For a complete description of the sampler, see Attachment A. A Wildco® Kemmerer bottle will be used to collect water from the appropriate depth interval and used to fill the containers necessary for the nutrient analytical samples. Bacteria samples will be collected directly from the sample containers 1-foot below the lake surface. Both samplers will have the appropriate depth intervals marked on the cables used for lowering them.

Sample collection equipment will be decontaminated prior to collection at each sample site using an Alconox® and distilled water solution and rinsed using distilled water. Sample collection equipment will be flushed with lake water at each sample location after decontamination prior to collecting samples. For samples collected between depth intervals, the sample collection equipment will be flushed once with lake water at each depth interval prior to collection.

Analytical samples will be collected in the following order based on their sensitivity to loss or contamination: TAH, PAH and then bacteria. The remaining samples can be collected in any order and include color, chlorophyll a, total phosphorus, total filterable phosphorus, filterable reactive phosphorus, Kjeldahl nitrogen, ammonia, nitrate+nitrite, particulate organic carbon and alkalinity.

When collecting samples for dissolved analyses (filterable reactive phosphorus, total filterable phosphorus and particulate organic carbon), a 0.45-micron, high-capacity, disposable filter will be attached to flexible Teflon® tubing that has been threaded through a peristaltic pump. Prior to filling sample bottles, the tubing and filter will be flushed with approximately 500-mL of lake water from the Kemmerer water sampling bottle. Each sample bottle will be filled with lake water pumped through the filter into the sample container. A new filter and associated tubing will be used for each sample location.

Samples will be kept in a cooler with gel ice at approximately 4° C for transport to the laboratory. Samples collected for the bacteria analyses (fecal coliform and E. coli) have a 6-hour holding time prior to filtration. Samples collected at Big Lake on Sundays will be transported to the laboratory in Anchorage upon completion of sampling that day for analysis to be completed within their holding times. Specific methods for collecting analytical samples and field parameters are provided in Section B2 of the QAPP.

3.2 Field Parameters

Field parameters will be measured after collection of analytical samples using a Horiba® U-22. Water quality parameters to be measured in the field include temperature, pH, dissolved oxygen, conductivity and turbidity. Measurements will be recorded every meter to the lake bottom at each sampling location. Transparency will be measured with a Secchi disk at each sampling location. Specific methods for measuring Secchi depth transparency are included in Section B2 of the QAPP. Information on field instrument calibration and maintenance is detailed in Section B6 of the QAPP.



FIELD GUIDE FOR COLLECTING SAMPLES FOR ANALYSIS OF VOLATILE ORGANIC COMPOUNDS IN STREAM WATER FOR THE NATIONAL WATER-QUALITY ASSESSMENT PROGRAM

By Larry R. Shelton

U.S. GEOLOGICAL SURVEY Open-File Report 97-401

Sacramento, California 1997

U.S. DEPARTMENT OF THE INTERIOR BRUCE BABBITT, Secretary

U.S. GEOLOGICAL SURVEY Gorden P. Eaton, Director

The use of firm, trade, brand names in this report is for identification purposes only and does not constitute endorsement by the U.S. Geological Survey.

For printed copies of the published report contact:

U.S. Geological Survey Field Technical Support, NAWQA Placer Hall, 6000 J St. Sacramento, Ca. 95819

CONTENTS

Glossary
Abstract
Introduction
Overview
Preparation for sample collection
Site selection
Sampling Equipment
Sampler

Support Equipment

Equipment cleaning

Sample collection procedures

Preparation

Routine sampling

Dip sampling

Sample processing procedures

Field measurements

Quality assurance and quality control

Field blanks

Trip blanks

Field-matrix spikes

Replicate samples

Documentation

Sample identification

Shipping

References cited

Appendix - Selected technical memorandums

FIGURES

1. Schematic of the volatile organic compound (VOC) sampler.

TABLES

- 1. List of volatile organic compound analytes for the National Water-Quality Assessment Program
 2. List of equipment and supplies for collecting and processing stream-water volatile organic
- 2. List of equipment and supplies for collecting and processing stream-water volatile organic compound (VOC) samples

CONVERSION FACTORS, ABBREVIATIONS, AND ACRONYMS

Conversion Factors

Multiply	Ву	To obtain
<pre>foot (ft) gallon (gal) inch (in.)</pre>	0.3048 3.785 25.4	meter liter millimeter

Temperature is given in degrees Celsius (C), which can be converted to degrees Fahrenheit (F) by the following equation: F=1.8(C)+32

Abbreviations

L, liter mg/L, microgram per liter mL, milliliter lb, pound

ASR, analytical services request DIW, deionized water FS, field spike FSR, field-spike replicate HCL, hydrochloric acid ID, identification QA, quality assurance QC, quality control VBW, pesticide/volatile blank water VG, VOC grade blank VOC, volatile organic compound

Acronyms

NAWQA, National Water-Quality Assessment NWQL, National Water Quality Laboratory USGS, U.S. Geological Survey WRD, Water Resources Division

GLOSSARY

Environmental Setting -- Land areas characterized by a unique, homogeneous combination of natural and human-related factors, such as row-crop cultivation on glacial-till soils.

Gaging station -- A fixed site on a stream or river where hydrologic and environmental data are collected.

Indicator Sites -- Stream sampling sites located at outlets of drainage basins with relatively homogeneous land use and physiographic conditions. Basins are as large and representative as possible, but still encompassing primarily one Environmental Setting (typically 50 to 500\x11km2).

Integrator Site -- Stream sampling sites located downstream from drainage basins that are large and complex and commonly contain multiple Environmental Settings. Most Integrator Sites are on major streams with drainage basins that include a substantial portion of the Study Unit area (typically, 10 to 100 percent).

Point sample -- A sample collected at a single point in the stream cross section and at a single point in the stream vertical.

Study Unit -- A major hydrologic system of the United States in which NAWQA studies are focused. NAWQA Study Units are geographically defined by a combination of ground- and surface-water features and usually encompass more than 10,000 km2 of land area. The NAWQA design is based on assessment of these Study Units, which collectively cover a large part of the Nation, encompass the majority of population and water use, and include diverse hydrologic systems that differ widely in natural and human factors that affect water quality.

Water-Column Studies -- Assessment of physical and chemical characteristics of stream water, including suspended sediment, dissolved solids, major ions and metals, nutrients, organic carbon, and dissolved pesticides, in relation to hydrologic conditions, sources, and transport.

Field Guide For Collecting Samples For Analysis of Volatile Organic Compounds In Stream Water For The National Water-quality Assessment Program

Abstract

For many years, stream samples for analysis of volatile organic compounds have been collected without specific guidelines or a sampler designed to avoid analyte loss. In 1996, the U.S. Geological Survey's National Water-Quality Assessment Program began aggressively monitoring urban stream-water for volatile organic compounds. To assure representative samples and consistency in collection procedures, a specific sampler was designed to collect samples for analysis of volatile organic compounds in stream water. This sampler, and the collection procedures, were tested in the laboratory and in the field for compound loss, contamination, sample reproducibility, and functional capabilities. This report describes that sampler and its use, and outlines field procedures specifically designed to provide contaminant-free, reproducible volatile organic compound data from stream-water samples.

These guidelines and the equipment described represent a significant change in U.S. Geological Survey instructions for collecting and processing stream-water samples for analysis of volatile organic compounds. They are intended to produce data that are both defensible and interpretable, particularly for concentrations below the microgram-per-liter level. The guidelines also contain detailed recommendations for quality-control samples.

INTRODUCTION

One of the goals of the National Water-Quality Assessment (NAWQA) Program of the U.S. Geological Survey (USGS) (Hirsch and others, 1988) is to establish a network of comprehensive and integrated urban water-quality studies to develop an understanding of the occurrence, significance, sources, movement, and fate of environmental chemicals in urbanized hydrologic systems (Lopes and Price, 1997; Squillace and Price, 1996). The occurrence of many contaminants, including volatile compounds, are being assessed in urban areas. For the information to be comparable among studies in different parts of the Nation, consistent procedures and equipment specifically designed to produce contaminant-free, reproducible volatile organic compound (VOC) data from stream-water samples are critical.

The assessment of VOCs in stream water is part of the Water-Column Studies (Gilliom and others, 1995), which focus on assessing the occurrence, concentrations and seasonal distribution of VOCs (Lopes and Price, 1997). The purpose of this report is to describe the equipment used to sample VOCs in streams and the procedures for using the VOC sampler. Companion reports by Koterba and others (1996) outline the procedures used for collecting VOC samples in ground-water, and Majewski and Capel (1995) discuss sampling of pesticides in the atmosphere.

The glossary at the front of this report includes brief definitions of some terms used in this report. Key terms used to describe the NAWQA Program are capitalized. Trade names used in connection with equipment or supplies do not constitute an endorsement of the product.

OVERVIEW

The sampling designs for stream-water studies rely on coordinated sampling of varying intensity and scope at two general types of sites, Integrator Sites and Indicator Sites. Integrator Sites are chosen to represent water-quality conditions of streams and rivers in the large basins affected by complex combinations of land-use settings, point sources, and natural influences. Indicator Sites, in contrast, are chosen to represent water-quality conditions of streams with relatively homogeneous land use and, usually, are associated with smaller basins in specific Environmental Settings. Most, but not all VOC

samples will be collected at urban Indicator Sites located in residential and commercial areas. Site selection and sampling strategies for urban Indicator Sites are described in Lopes and Price (1997).

Two primary sampling strategies are used at the selected Integrator and Indicator Sites: (1) fixed interval sampling (usually monthly) characterizes the spatial and temporal distribution of contaminants in relation to hydrologic conditions and contaminant sources, and (2) intensive sampling characterizes seasonal and short-term temporal variability of contaminant transport during high flows and at more frequent fixed intervals.

Most VOCs are man-made compounds that are components of gasoline, by-products of chlorinating drinking water, or solvents. Laboratory analysis is done by the purge-and-trap technique to separate the VOCs from the water matrix, and the quantitation is done by capillary-column gas chromatography/mass spectrometry. Results are reported in micrograms per liter. The USGS National Water Quality Laboratory (NWQL) VOC analysis schedule 2020 will be used. The analytes are summarized in table 1.

PREPARATION FOR SAMPLE COLLECTION

Site Selection

All VOC sampling sites should be at or near streamflow gaging stations because stream discharges associated with contaminant concentrations are needed to evaluate relations between streamflow and water-quality characteristics (Gilliom and others, 1995; Lopes and Price, 1997). The sample collection site should not be more than a few hundred feet from the station.

Collection sites should be located in relatively straight channel reaches where the flow is uniform. Collecting samples directly in a ripple, or from ponded or sluggish water, should be avoided. Sites directly upstream or downstream of confluences or direct sources of contamination also should be avoided to minimize problems caused by backwater effects or poorly mixed flows. In addition, samples collected downstream from a bridge can be contaminated by runoff from the road surface. Proper field judgement is crucial to achieve a sample representative of the typical environmental conditions.

Samples should be collected at the centroid of the stream in the same cross section throughout the project. This will eliminate many of the potential problems that might arise during the interpretation of the data. This does not mean that the same section used during the low-water wading stage must be used during higher stages that require the use of a bridge or cableway. However, the flow characteristics at different cross sections can result in incomparable data if the cross sections are not located near each other or in the same flow regime. Rapidly changing stage, discharge, and constituent concentrations dictate that sampling schemes and techniques be planned carefully in advance to ensure that representative samples are obtained.

Table 1. List of volatile organic compound analytes for the National Water-Quality Assessment Program.

[CAS, Chemical Abstract Service number; PCODE, USGS Parameter Code]					
	Labora	atory a	nalyses: Schedule Number 202		
CAS	number	PCODE	Compound		

Halogenated Alkanes

630-20-6	77562	1,1,1,2-Tetrachloroethane			
71-55-6		1,1,1-Trichloroethane			
79-34-5	34516	1,1,2,2-Tetrachloroethane			
76-13-1	77652	1,1,2-Trichloro-1,2,2-trifluoroethane			
79-00-5	34511	1,1,2-Trichloroethane			
75-34-3	34496	1,1-Dichloroethane			
	77443	1,2,3-Trichloropropane			
96-12-8		1,2-Dibromo-3-chloropropane			
106-93-4		1,2-Dibromoethane			
107-06-2	32103	1,2-Dichloroethane			
78-87-5	34541	1,2-Dichloropropane			
		1,3-Dichloropropane			
142-28-9 594-20-7	77173				
	77170	2,2-Dichloropropane			
74-97-5	77297	Bromochloromethane			
75-27-4	32101	Bromodichloromethane			
	34413	Bromomethane			
124-48-1		Chlorodibromomethane			
75-00-3		Chloroethane			
74-87-3		Chloromethane			
74-95-3		Dibromomethane			
75-71-8	34668	Dichlorodifluoromethane			
75-09-2	34423	Dichloromethane			
67-72-1	34396	Hexachloroethane			
74-88-4	77424	Iodomethane			
56-23-5		Tetrachloromethane			
75-25-2		Tribromomethane			
75-69-4		Trichlorofluoromethane			
67-66-3	32106	Trichloromethane			
II.a.l. a.	7 1 1				
Halogenated	Alkenes				
-		1.1-Dichloroethene			
75-35-4	34501	1,1-Dichloroethene			
75-35-4 563-58-6	34501 77168	1,1-Dichloropropene			
75-35-4 563-58-6 107-05-1	34501 77168 78109	<pre>1,1-Dichloropropene 3-Chloro-1-propene</pre>			
75-35-4 563-58-6 107-05-1 593-60-2	34501 77168 78109 50002	<pre>1,1-Dichloropropene 3-Chloro-1-propene Bromoethene</pre>			
75-35-4 563-58-6 107-05-1 593-60-2 75-01-4	34501 77168 78109 50002 39175	1,1-Dichloropropene 3-Chloro-1-propene Bromoethene Chloroethene			
75-35-4 563-58-6 107-05-1 593-60-2 75-01-4 87-68-3	34501 77168 78109 50002 39175 39702	1,1-Dichloropropene 3-Chloro-1-propene Bromoethene Chloroethene Hexachlorobutadiene			
75-35-4 563-58-6 107-05-1 593-60-2 75-01-4 87-68-3 127-18-4	34501 77168 78109 50002 39175 39702 34475	1,1-Dichloropropene 3-Chloro-1-propene Bromoethene Chloroethene Hexachlorobutadiene Tetrachloroethene			
75-35-4 563-58-6 107-05-1 593-60-2 75-01-4 87-68-3 127-18-4 79-01-6	34501 77168 78109 50002 39175 39702 34475 39180	1,1-Dichloropropene 3-Chloro-1-propene Bromoethene Chloroethene Hexachlorobutadiene Tetrachloroethene Trichloroethene			
75-35-4 563-58-6 107-05-1 593-60-2 75-01-4 87-68-3 127-18-4 79-01-6 156-59-2	34501 77168 78109 50002 39175 39702 34475 39180 77093	1,1-Dichloropropene 3-Chloro-1-propene Bromoethene Chloroethene Hexachlorobutadiene Tetrachloroethene Trichloroethene cis-1,2-Dichloroethene			
75-35-4 563-58-6 107-05-1 593-60-2 75-01-4 87-68-3 127-18-4 79-01-6 156-59-2 10061-01-5	34501 77168 78109 50002 39175 39702 34475 39180 77093 34704	1,1-Dichloropropene 3-Chloro-1-propene Bromoethene Chloroethene Hexachlorobutadiene Tetrachloroethene Trichloroethene cis-1,2-Dichloroethene cis-1,3-Dichloropropene			
75-35-4 563-58-6 107-05-1 593-60-2 75-01-4 87-68-3 127-18-4 79-01-6 156-59-2 10061-01-5 156-60-5	34501 77168 78109 50002 39175 39702 34475 39180 77093 34704 34546	1,1-Dichloropropene 3-Chloro-1-propene Bromoethene Chloroethene Hexachlorobutadiene Tetrachloroethene Trichloroethene cis-1,2-Dichloroethene cis-1,3-Dichloropropene trans-1,2-Dichloroethene			
75-35-4 563-58-6 107-05-1 593-60-2 75-01-4 87-68-3 127-18-4 79-01-6 156-59-2 10061-01-5 156-60-5 10061-02-6	34501 77168 78109 50002 39175 39702 34475 39180 77093 34704 34546 34699	1,1-Dichloropropene 3-Chloro-1-propene Bromoethene Chloroethene Hexachlorobutadiene Tetrachloroethene Trichloroethene cis-1,2-Dichloroethene cis-1,3-Dichloropropene trans-1,2-Dichloroethene			
75-35-4 563-58-6 107-05-1 593-60-2 75-01-4 87-68-3 127-18-4 79-01-6 156-59-2 10061-01-5 156-60-5	34501 77168 78109 50002 39175 39702 34475 39180 77093 34704 34546	1,1-Dichloropropene 3-Chloro-1-propene Bromoethene Chloroethene Hexachlorobutadiene Tetrachloroethene Trichloroethene cis-1,2-Dichloroethene cis-1,3-Dichloropropene trans-1,2-Dichloroethene			
75-35-4 563-58-6 107-05-1 593-60-2 75-01-4 87-68-3 127-18-4 79-01-6 156-59-2 10061-01-5 156-60-5 10061-02-6	34501 77168 78109 50002 39175 39702 34475 39180 77093 34704 34546 34699 73547	1,1-Dichloropropene 3-Chloro-1-propene Bromoethene Chloroethene Hexachlorobutadiene Tetrachloroethene Trichloroethene cis-1,2-Dichloroethene cis-1,3-Dichloropropene trans-1,2-Dichloroethene			
75-35-4 563-58-6 107-05-1 593-60-2 75-01-4 87-68-3 127-18-4 79-01-6 156-59-2 10061-01-5 156-60-5 10061-02-6 110-57-6 Aromatic Hyd	34501 77168 78109 50002 39175 39702 34475 39180 77093 34704 34546 34699 73547	1,1-Dichloropropene 3-Chloro-1-propene Bromoethene Chloroethene Hexachlorobutadiene Tetrachloroethene Trichloroethene cis-1,2-Dichloroethene cis-1,3-Dichloropropene trans-1,2-Dichloroethene trans-1,2-Dichloroethene			
75-35-4 563-58-6 107-05-1 593-60-2 75-01-4 87-68-3 127-18-4 79-01-6 156-59-2 10061-01-5 156-60-5 10061-02-6 110-57-6 Aromatic Hyd	34501 77168 78109 50002 39175 39702 34475 39180 77093 34704 34546 34699 73547 drocarbons	1,1-Dichloropropene 3-Chloro-1-propene Bromoethene Chloroethene Hexachlorobutadiene Tetrachloroethene Trichloroethene cis-1,2-Dichloroethene cis-1,3-Dichloropropene trans-1,2-Dichloropropene trans-1,2-Dichloropropene trans-1,3-Dichloropropene brans-1,4-Dichloro-2-butene			
75-35-4 563-58-6 107-05-1 593-60-2 75-01-4 87-68-3 127-18-4 79-01-6 156-59-2 10061-01-5 156-60-5 10061-02-6 110-57-6 Aromatic Hyd	34501 77168 78109 50002 39175 39702 34475 39180 77093 34704 34546 34699 73547 drocarbons	1,1-Dichloropropene 3-Chloro-1-propene Bromoethene Chloroethene Hexachlorobutadiene Tetrachloroethene Trichloroethene cis-1,2-Dichloroethene cis-1,3-Dichloropropene trans-1,2-Dichloroethene trans-1,4-Dichloro-2-butene Benzene Naphthalene			
75-35-4 563-58-6 107-05-1 593-60-2 75-01-4 87-68-3 127-18-4 79-01-6 156-59-2 10061-01-5 156-60-5 10061-02-6 110-57-6 Aromatic Hyd	34501 77168 78109 50002 39175 39702 34475 39180 77093 34704 34546 34699 73547 drocarbons	1,1-Dichloropropene 3-Chloro-1-propene Bromoethene Chloroethene Hexachlorobutadiene Tetrachloroethene Trichloroethene cis-1,2-Dichloroethene cis-1,3-Dichloropropene trans-1,2-Dichloropropene trans-1,2-Dichloropropene trans-1,3-Dichloropropene brans-1,4-Dichloro-2-butene			
75-35-4 563-58-6 107-05-1 593-60-2 75-01-4 87-68-3 127-18-4 79-01-6 156-59-2 10061-01-5 156-60-5 10061-02-6 110-57-6 Aromatic Hyd	34501 77168 78109 50002 39175 39702 34475 39180 77093 34704 34546 34699 73547 drocarbons 34030 34696 77128	1,1-Dichloropropene 3-Chloro-1-propene Bromoethene Chloroethene Hexachlorobutadiene Tetrachloroethene Trichloroethene cis-1,2-Dichloroethene cis-1,3-Dichloropropene trans-1,2-Dichloroethene trans-1,4-Dichloro-2-butene Benzene Naphthalene			
75-35-4 563-58-6 107-05-1 593-60-2 75-01-4 87-68-3 127-18-4 79-01-6 156-59-2 10061-01-5 156-60-5 10061-02-6 110-57-6 Aromatic Hyd 71-43-2 91-20-3 100-42-5 Alkyl Benzer	34501 77168 78109 50002 39175 39702 34475 39180 77093 34704 34546 34699 73547 drocarbons 34030 34696 77128	1,1-Dichloropropene 3-Chloro-1-propene Bromoethene Chloroethene Hexachlorobutadiene Tetrachloroethene Trichloroethene cis-1,2-Dichloroethene cis-1,3-Dichloropropene trans-1,2-Dichloroethene trans-1,4-Dichloro-2-butene Benzene Naphthalene Styrene			
75-35-4 563-58-6 107-05-1 593-60-2 75-01-4 87-68-3 127-18-4 79-01-6 156-59-2 10061-01-5 156-60-5 10061-02-6 110-57-6 Aromatic Hyd 71-43-2 91-20-3 100-42-5 Alkyl Benzer 488-23-3	34501 77168 78109 50002 39175 39702 34475 39180 77093 34704 34546 34699 73547 drocarbons 34030 34696 77128	1,1-Dichloropropene 3-Chloro-1-propene Bromoethene Chloroethene Hexachlorobutadiene Tetrachloroethene Trichloroethene cis-1,2-Dichloroethene cis-1,3-Dichloropropene trans-1,2-Dichloroethene trans-1,4-Dichloropropene trans-1,4-Dichloro-2-butene Benzene Naphthalene Styrene 1,2,3,4-Tetramethylbenzene			
75-35-4 563-58-6 107-05-1 593-60-2 75-01-4 87-68-3 127-18-4 79-01-6 156-59-2 10061-01-5 156-60-5 10061-02-6 110-57-6 Aromatic Hyc 71-43-2 91-20-3 100-42-5 Alkyl Benzer 488-23-3 527-53-7	34501 77168 78109 50002 39175 39702 34475 39180 77093 34704 34546 34699 73547 drocarbons 34030 34696 77128	1,1-Dichloropropene 3-Chloro-1-propene Bromoethene Chloroethene Hexachlorobutadiene Tetrachloroethene Trichloroethene cis-1,2-Dichloroethene cis-1,3-Dichloropropene trans-1,2-Dichloroethene trans-1,2-Dichloropropene trans-1,4-Dichloro-2-butene Benzene Naphthalene Styrene 1,2,3,4-Tetramethylbenzene 1,2,3,5-Tetramethylbenzene			
75-35-4 563-58-6 107-05-1 593-60-2 75-01-4 87-68-3 127-18-4 79-01-6 156-59-2 10061-01-5 156-60-5 10061-02-6 110-57-6 Aromatic Hyd 71-43-2 91-20-3 100-42-5 Alkyl Benzer 488-23-3 527-53-7 526-73-8	34501 77168 78109 50002 39175 39702 34475 39180 77093 34704 34546 34699 73547 drocarbons 34030 34696 77128	1,1-Dichloropropene 3-Chloro-1-propene Bromoethene Chloroethene Hexachlorobutadiene Tetrachloroethene Trichloroethene cis-1,2-Dichloroethene cis-1,3-Dichloropropene trans-1,2-Dichloropropene trans-1,2-Dichloropropene trans-1,4-Dichloro-2-butene Benzene Naphthalene Styrene 1,2,3,4-Tetramethylbenzene 1,2,3,5-Tetramethylbenzene 1,2,3-Trimethylbenzene			
75-35-4 563-58-6 107-05-1 593-60-2 75-01-4 87-68-3 127-18-4 79-01-6 156-59-2 10061-01-5 156-60-5 10061-02-6 110-57-6 Aromatic Hyc 71-43-2 91-20-3 100-42-5 Alkyl Benzer 488-23-3 527-53-7	34501 77168 78109 50002 39175 39702 34475 39180 77093 34704 34546 34699 73547 drocarbons 34030 34696 77128	1,1-Dichloropropene 3-Chloro-1-propene Bromoethene Chloroethene Hexachlorobutadiene Tetrachloroethene Trichloroethene cis-1,2-Dichloroethene cis-1,3-Dichloropropene trans-1,2-Dichloroethene trans-1,2-Dichloropropene trans-1,4-Dichloro-2-butene Benzene Naphthalene Styrene 1,2,3,4-Tetramethylbenzene 1,2,3,5-Tetramethylbenzene			

108-67-8 108-38-3 106-42-3 611-14-3 100-41-4 98-82-8 108-88-3 104-51-8 103-65-1 99-87-6 135-98-8 98-06-6	77226 85795 77220 34371 77223 34010 77342 77224 77356 77350 77353	1,3,5-Trimethylbenzene 1,3-Dimethylbenzene 1,4-Dimethylbenzene 2-Ethyltoluene Ethylbenzene Isopropylbenzene Methylbenzene n-Butylbenzene n-Propylbenzene p-Isopropyltoluene sec-Butylbenzene tert-Butylbenzene
Halogenated A	romatics	
87-61-6 120-82-1 95-50-1 541-73-1 106-46-7 95-49-8 106-43-4 108-86-1 108-90-7	77613 34551 34536 34566 34571 77275 77277 81555 34301	1,2,3-Trichlorobenzene 1,2,4-Trichlorobenzene 1,2-Dichlorobenzene 1,3-Dichlorobenzene 1,4-Dichlorobenzene 2-Chlorotoluene 4-Chlorotoluene Bromobenzene Chlorobenzene
Ethers and ot	her Oxygen	ated Compounds
78-93-3 591-78-6 108-10-1 67-64-1 60-29-7 108-20-3 637-92-3 1634-04-4 109-99-9 994-05-8	81595 77103 78133 81552 81576 81577 50004 78032 81607 50005	2-Butanone 2-Hexanone 4-Methyl-2-pentanone Acetone Diethyl ether Diisopropyl ether Ethyl tert-butyl ether Methyl tert-butyl ether Tetrahydrofuran tert-Amyl methyl ether
Others		
107-02-8 107-13-1 75-15-0 97-63-2 96-33-3 126-98-7 80-62-6	34210 34215 77041 73570 49991 81593 81597	2-Propenal 2-Propenenitrile Carbon disulfide Ethyl methacrylate Methyl acrylate Methyl acrylonitrile Methyl methacrylate

Sampling Equipment

Sampler

Obtaining representative VOC samples in flowing streams is a difficult task. Of critical importance is the design and operation of the equipment and the sampling procedure (Brown and others, 1970). Samplers must be designed to collect an unbiased sample of environmental conditions. One important process is to flush atmospheric gases from the sampler before collecting a stream sample (Kilpatrick and

others, 1989).

A newly developed VOC sampler designed by the USGS and built by Wildco (fig. 1) will be used to collect stream-water samples for VOC analysis. This sampler has been tested for analyte loss, reproducibility, and carryover contamination in the laboratory and in field settings. The sampler, which is made of noncontaminating materials (stainless steel and refrigeration-grade copper) that will not sorb the analytes of interest, can collect a sample representative of environment conditions in most streams. An important function of the sampler design is to evacuate air and other gases from the sampler before collecting a sample. The VOC sampler weighs 11 lb and can be suspended, by hand, from a short rope or chain while wading a stream. However, when sampling during periods of high flow, 10-lb weights can be added to keep the sampler vertical when it is suspended from a bridge or cableway.

The sampler is designed to collect a sample at a single point in the stream. The stainless-steel sampler holds four 40-mL vials. Copper tubes extend to the bottom of each vial from the inlet ports on top of the sampler. The vials fill and overflow into the sampler body, displacing the air in the vials and in the sampler through the exhaust tube. The total volume of the sampler is eight times larger then the vials; therefore, the vials are flushed seven times (removing the air) before the final volume is retained in the vial. The small (1/16-in. inside diameter) copper inlet ports results in a slow (3 to 4 minutes) filling time. This important design feature helps to produce a representative sample and allows sufficient time to place the sampler at the desired depth. The sampler begins to fill as soon as it enters the stream; however, the final sample is retained in the vial during the last 15 to 20 seconds of the filling process. A cover over the inlet ports prevents contamination from surface oil and debris when the sampler is removed from the stream.




Figure 1. Schematic of volatile organic compound (VOC) sampler. The sampler body is made of stainless steel, weighs 11 pounds, and is 6 inches in diameter and 6 inches high. It has an air exhaust tube extending above the sampler, and four copper inlet tubes that extend into four 40-milliliter sample vials.




Figure 1. Schematic of volatile organic compound (VOC) sampler. The sampler body is made of stainless steel, weighs 11 pounds and is 6 inches high. It has an air exhaust tube extending above the sampler, and four copper inlet tubes that extend into four 40-milliliter sample vials.

Support Equipment

Field vehicles are commonly used for more than one purpose (such as streamflow measurements, gaging station maintenance, construction, stream sampling, and sample processing). Sample contamination is more likely to occur when these multiuse vehicles are used to collect and process water samples. Glues and adhesives used in vehicles, and the cabinet construction, can contaminate samples for VOCs. Therefore, it is important that the processing area be free of contaminants, plastics, dirt, fumes, and oil residue. Samples should be removed from the sampler, processed, and capped streamside to avoid possible contaminants in the vehicles. Each vehicle should have a separate storage area for the VOC sampling equipment and supplies. A complete equipment list is given in table 2.

Table 2. List of equipment and supplies for collecting and processing stream-water volatile organic compound (VOC) samples.

[Sources for some items are listed to maintain quality standards. OCALA, USGS Water-Quality Service

Sampling equipment and supplies

```
Volatile organic compound (VOC) sampler (Wildco 990-J98) Vial, glass, amber septum, 40 milliliter (NWQL and OCALA 333FLD) Rope, nylon, 1/4-inch diameter (OCALA 84FLD)
```

Cleaning and storing equipment and supplies

```
Gloves, vinyl, powderless (OCALA 155HWS)
Detergent, phosphate free, 0.2 percent by volume (OCALA 62FLD)
Methanol, pesticide grade
Deionized water
VOC grade blank water (VG or VBW) (NWQL)
Bottles, wash, plastic, for detergent (OCALA 357FLD)
Bottles, wash, Teflon, for VG water (OCALA 377FLD)
Bottles, wash, Teflon, for methanol (OCALA 377FLD)
Basins, wash, plastic (2)
Brush, scrub, soft metallic
Bag, plastic, sealable, medium (OCALA 23FLD)
Storage container, sealable, 8 inches x 8 inches x 12 inches
Foil, aluminum, heavy duty
Container, waste, solvent, 5 gallons
```

Processing equipment and supplies

```
Cannister, stainless steel, 8 quarts with cover (for field blanks) Flask tongs
Gloves, vinyl, powderless (OCALA 155HWS)
Hydrochloric acid 1:1 acid, in Teflon vials (NWQL)
Kit, matrix spike (NWQL)
pH paper (alkacid test ribbon)
Bottle labels (OCALA 84FLD)
Sleeves, foam (OCALA 358FLD)
Coolers, shipping, 1 gallon
Coolers, shipping, 5 gallon s
Bags, plastic, 5 gallons
Ice
```

Miscellaneous equipment and supplies

```
Boots, hip
Waders, chest
Tools
First aid kit
Highway emergency kit
Forms, field documentation (OCALA)
Forms, analytical request (NWQL)
Tissues, laboratory
Pens, marking, permanent, (OCALA 77FLD)
Field meters, conductance, pH, dissolved oxygen
Supplies for field measurements
```

EQUIPMENT CLEANING

All equipment that will come in contact with the sample should be soaked in a dilute phosphate-free detergent solution; rinsed with tap water, VOC grade blank (VG) water, and methanol; and then air dried prior to each field trip and between sites (Shelton, 1994). Detergents and methanol should be used with care to avoid the possibility of the residue contaminating the sample. A thorough native-water rinse is required at each field site before sampling to remove any remaining cleaning agents and to equilibrate the equipment to the sampling conditions. A list of the supplies needed for equipment cleaning is given in table 2, and detailed procedures for cleaning the VOC sampler are outlined below.

- 1. Open sampler.
- 2. Submerge top and base in a 0.2-percent solution of phosphate-free detergent. Scrub the sampler thoroughly with a nylon brush. Use a small squeeze bottle, filled with the detergent, to flush the copper tubing.
- 3. Rinse the sampler thoroughly with warm tap water or deionized water (DIW) to remove all soap residue.
- 4. Using a Teflon squeeze bottle, rinse with a minimum amount of methanol. Place the used methanol in a waste container for proper disposal (see Water Resources Division [WRD] memorandum 94.07, Appendix).
- 5. Allow to air dry (cover loosely with aluminum foil to avoid airborne contamination). If complete air drying is not possible, rinse three times with VG water.
- 6. Wearing vinyl gloves, reassemble the sampler.
- 7. Wrap areas that will come in contact with the sample with aluminum foil, and place in a sealable plastic bag. Use a large sealed container to protect the sampler in storage and during transport.
- 8. Rinse the sampler (without the vials) with 2 to 3 L of native water prior to sampling.

SAMPLE COLLECTION PROCEDURES

Preparation

The timing of the VOC sampling should be planned to avoid possible contamination by other collection and processing activities (such as procedures and equipment that use methanol). Before beginning any other activity collect and process the VOC samples at the site. The entire sampling and processing procedure (removing it from the storage container, loading the sampler, sampling, and acidifying the sample) should be done at streamside, well away from other processing activities.

Routine Sampling

VOC samples should be collected where the stream velocity represents the average flow, which is typically near mid-channel in the cross section. The following procedure is designed to produce a single-vertical point sample. When collecting samples for VOC analyses, special care must be taken to avoid contamination from any oily film and debris floating on the stream surface. The samples should be collected directly into the prebaked 40-mL amber-glass vials as follows:

- 1. Reclean the sampler, if necessary (see 'Equipment Cleaning' section).
- 2. Transport the sampler to the collection site and rinse three times with native water or submerge it in the stream for several minutes.
- 3. In a protected area, away from any direct source of contamination and wearing vinyl gloves,

- uncap four 40-mL unlabeled vials and place them in the sampler. Secure and lock the sampler top in position. Store the vial caps in a protected area.
- 4. Lower the sampler into the stream near mid-channel to about one half of the total depth at that vertical. Add weights if the stream velocity is great enough to pull the sampler downstream.
- 5. Collect a sample by holding the sampler in one position until the sampler is full. Air bubbles will rise to the surface while the sampler is being filled, but may be difficult to see. This takes about 3 to 4 minutes. The sample will be retained in the vial during the last 15 to 20 seconds of sampling.
- 6. Remove the sampler when bubbles are no longer present or after about 5 minutes, and return to a protected area at the side of the stream for processing.

Dip Sampling

In very shallow streams where the VOC sampler cannot be submerged, a representative sample usually can be obtained manually by immersing an open vial (dip sample) near the centroid of flow. Wearing vinyl gloves, lower a 40-mL vial to about one half of the stream depth. Point the vial into the stream current, remove the cap, allow the vial to fill, then slowly bring it to the surface. Add hydrochloric acid (HCL), carefully cap the vial, and check for air bubbles that may be trapped in the vial. A dip sample should never be taken when it is possible to use the sampler. Consistent procedures will avoid the possibility of a sampling bias.

SAMPLE PROCESSING PROCEDURES

Biodegradation and chemical reactions, such as oxidation and volatilization, can change many of the compounds present in natural waters before analyses in a laboratory. Therefore, samples must be preserved as soon as possible after collection. The method of preserving VOCs includes the addition of 1:1 HCL and refrigeration to 4°C to arrest microbiological activity and to minimize volatilization. Great care must be exercised in the field to prevent compound loss or sample contamination. Because exhaust fumes and adhesives in field vehicles may be a source of contamination, processing samples streamside can best prevent contamination. Evaluate trip and field blanks to confirm that the processing area is appropriate.

To preserve the samples, add 1:1 HCL to lower the pH to 2 or less, and immediately place the vials on ice. To determine the volume of acid to add, collect a hand dipped test sample in a used 40-mL vial. Add HCL to the test sample to lower the sample pH to less than 2.0. Two drops of HCL should be adequate for most conditions; however, some environmental samples may require additional HCL. At no time should you use more than six drops of HCL. Alkacid test ribbons can be used to estimate the pH.

By following this sequence for sample preservation, the risk of contaminating a sample is reduced. Acid should be stored and transported properly (see WRD memorandum 94.06, Appendix). These procedures are summarized below.

- 1. Wearing vinyl gloves, open the sampler carefully at streamside.
- 2. Using metal tongs, slowly lift each vial from the sampler reservoir. Do this carefully to avoid losing the convex meniscus.
- 3. Add drops (usually two, but no more than six) of 1:1 HCL to lower the pH to less than 2, and cap the vial.
- 4. Agitate the vial and check for air bubbles. Discard if bubbles are present.
- 5. Three vials from the same sampler set are required for one complete sample. Resample completely, if necessary.
- 6. Label the samples, wrap each with a foam sleeve, and place them on ice.

7. Clean the sampler and store it properly (see 'Equipment Cleaning' section).

The minimum information required on each vial is the site identification (ID) number, date and time sampled, preservation, and schedule number, as shown on the example below:

09498500 04-24-1997 @ 1200 HCL to <2.0 pH SCH - 2020

FIELD MEASUREMENTS

Water temperature, specific conductance, pH, dissolved oxygen, and alkalinity could change dramatically within minutes or hours after sample collection. Immediate analysis in the field is required if the results are to be representative of in-stream conditions.

Water temperature and dissolved oxygen should be measured directly from the stream, and several readings are required in the cross section to obtain a stream average. A composite stream sample should be collected for specific conductance, pH, and alkalinity. A single field meter that measures specific conductance, water temperature, pH, and dissolved oxygen directly in the stream may be used. Detailed information on the procedures, equipment, and supplies necessary for the field analyses is presented in reports by Shelton (1994) and Wilde and Radtke (in press).

QUALITY ASSURANCE AND QUALITY CONTROL

The sources of variability and bias introduced by sample collection and processing affect the interpretation of water-quality data. Quality-assurance (QA) plans ensure that the data collected are compatible and of sufficient quality to meet program objectives. These guidelines and the Study Unit design guidelines for NAWQA should be used when preparing QA plans. Specific details for QA plans are described by Shampine and others (1992).

Investigators in each Study Unit must document the quality of their data by collecting quality-control (QC) samples. A series of QC samples (blanks, replicates, and spikes) must be obtained during VOC investigations because the quality of the data collected, and the validity of any interpretation, cannot be evaluated without QC data. Detailed procedures for preparing QC samples for VOCs, and the recommended frequencies, are described in Mueller and others (1997).

Field Blanks

Field blanks are used to determine whether (1) equipment-cleaning protocols adequately remove residual contamination from previous use, (2) sampling and sample-processing procedures result in contamination, and (3) equipment handling and transport periods of sample collection do not introduce contamination. Field blanks for VOCs are collected immediately before processing a routine environmental sample. Load four 40-mL vials into the sampler. Pour VG water into a clean (see `Equipment Cleaning' section) stainless-steel cannister, and then collect two 40-mL vials from the cannister for the cannister-blank sample. Submerge the sampler containing four 40-mL vials in the cannister and allow to fill. Remove the vials and process the field and cannister blanks in the same manner as the environmental sample. Process the samples using the NWQL analytical schedule for environmental samples. If analytical results indicate carryover of residues, perform additional field tests to determine the source of the contamination. A more rigorous cleaning procedure might be necessary.

Field blanks produce the most valuable QC data to evaluate potential contamination.

Trip Blanks

Trip blanks are used to determine whether external VOCs from bottle handling and analytical processes, independent of the field sample processing scheme, are contaminating the samples. Trip blanks are provided upon request and are prepared and distributed to each Study Unit by the NWQL. These trip blanks bottles should be stored and transported with the other bottles used for collecting the environmental sample, and then submitted for analysis in the same manner. Trip blanks should never be opened in the field. If analytical results indicate that samples have been contaminated, additional blanks should be processed to identify the source. Trip blanks should only be prepared with field blanks.

Field-Matrix Spikes

Field-matrix spikes are designed to (1) assess recoveries from field matrices and (2) assist in evaluating the precision of results for the range of target analytes in different matrices. Biases and interferences can result from sample matrices and from other processes that occur from the time the sample vial is preserved in the field to the time the vial is analyzed in the laboratory. After collecting the environmental sample, immediately collect a second set of four vials for the field-matrix spikes and preserve each using HCL. Add a standard spike solution using a microliter gas-tight syringe. Matrix-spike kits (solution and syringe) with instructions are available from the NWQL. Label two vials 'FS' (field spike) and two vials 'FSR' (field-spike replicate). Record the lot number and volume of the spike solution on the field notes and on the NWQL analytical services request (ASR) form. Send each set of vials-two FS and two FSR-as separate sample sets, including the environmental sample, to the laboratory for analyses.

Replicate Samples

Sample replicates are designed to provide information needed to (1) estimate the precision of concentration values determined from the combined sample-processing and analytical method and (2) evaluate the consistency of identifying target analytes for VOCs. Each replicate sample is an aliquot of the environmental sample collected in the same sampler, processed at the same time, and stored and shipped in the same way. Compare the analytical results to determine if accurate, consistent data can be reproduced.

DOCUMENTATION

All field activities and site information should be documented on standard surface-water-quality field notes (Shelton, 1994). A complete documentation will aid in future analyses of the collected information

Field notes should include the following information:

- 1. Station name and number.
- 2. Date and time (1 minute earlier than environmental sample).
- 3. Gage height, discharge, or both; stage conditions.
- 4. Type of sample (single-vertical point sample).
- 5. Sampler (VOC sampler).
- 6. Sampling method (bridge, cableway, wading).
- 7. Depth and width of stream at sampling location.

- 8. Location within the cross section (midstream).
- 9. Depth of sampling (mid depth).
- 10. Field analyses and calibration (temperature, conductance, pH, alkalinity, oxygen).
- 11. Detailed alkalinity titration.
- 12. Type of samples collected (VOC, major ions, quality control, and others).
- 13. Name of sample collector(s).
- 14. Site information: color and odor of the stream, weather conditions, and others.

SAMPLE IDENTIFICATION

Consistent specific identification of samples is essential for national data aggregation. For this reason, a data-coding strategy has been developed for the NAWQA Program. Use the following instructions for coding information onto the water quality field notes and on the NWQL ASR forms. The most critical codes for proper sample identification are the station ID number, sample medium, and sample type. Different sample-time coding is specified to distinguish among multiple samples collected during the same site visit. VOC samples will have a time 1 minute earlier than all other environmental samples to segregate the VOC analytical results from other analyses. For QC samples, the time codes are used to establish a rationale for associating the necessary sample codes with each individual sample. Do not use fictitious station ID numbers for routine QC samples.

VOC Environmental Sample

STATION ID - Same as other environmental sample

DATE - Same as other environmental sample

TIME - One minute earlier than the other environmental samples

SAMPLE MEDIUM - '9' (surface water)

SAMPLE TYPE - '9' (regular)

Parameter 71999 (Sample purpose) - `15' (NAWQA)

Parameter 99111 (QA data with sample) - '10' (blank)

Field Blank

STATION ID - Same as environmental sample

DATE - Same as environmental sample

TIME - Exact time of preparation (different from other blanks)

SAMPLE MEDIUM - 'Q' (QA sample, artificial)

SAMPLE TYPE - `2' (blank)

COMMENTS - 'PREVIOUS SAMPLE AT:' station ID, date/time

Parameter 71999 (Sample purpose) - `15' (NAWQA)

Parameter 99102 (Type of blank sample) - `100' (field)

Parameter 99104 (Blank lot number) - Enter first five digits

Parameter 99101 (Source of blank solution) - `10' (NWQL)

Cannister Blank

STATION ID - Same as environmental sample

DATE - Same as environmental sample

TIME - One minute earlier than field blank (different from other blanks)

SAMPLE MEDIUM - 'O' (OA sample, artificial)

SAMPLE TYPE - `B' (other)

COMMENTS - 'CANNISTER BLANK'

Parameter 71999 (Sample purpose) - `15' (NAWQA)

Parameter 99102 (Type of blank sample) - `100' (field)

Parameter 99104 (Blank lot number) - Enter first five digits

Parameter 99101 (Source of blank solution) - '10' (NWQL)

Trip Blank

STATION ID - Same as environmental sample

DATE - Same as environmental sample

TIME - Exact time of preparation (end of trip)

SAMPLE MEDIUM - 'Q' (QA sample, artificial)

SAMPLE TYPE - '2' (blank)

Parameter 71999 (Sample purpose) - '15' (NAWQA)

Parameter 99102 (Type of blank sample) - '30' (trip)

Parameter 99101 (Source of blank solution) - `10' (NWQL)

Parameter 99109 (Start date YMMDD) - Date blanks received from NWQL

Parameter 99110 (End date YMMDD) - Date trip blanks shipped to NWQL

Field-Matrix Spike

STATION ID - Same as environmental sample

DATE - Same as environmental sample

TIME - `SPIKE (FS)' 6 minutes later than environmental sample (HH:X6)

`SPIKE REPLICATE (FSR)' 7 minutes later than environmental sample (HH:X7)

SAMPLE MEDIUM - 'R' (OA surface water)

SAMPLE TYPE - `1' (spike)

COMMENTS - `FS or FSR', `SCH 9090 spike lot number '

Parameter 71999 (Sample purpose) - `15' (NAWQA)

Parameter 99104 (Spike lot number) - Enter first five digits

Parameter 99105 (Replicate type) - `10' (concurrent)

Parameter 99106 (Spike type) - `10' (field)

Parameter 99107 (Spike source) - '10' (NWQL)

Parameter 99108 (Spike volume) - volume used, in milliliters

Replicate Samples

STATION ID - Same as environmental sample

DATE - Same as environmental sample

TIME - Same as VOC environmental sample

SAMPLE MEDIUM - '9' (surface water)

SAMPLE TYPE - `7' (replicate)

Parameter 99111 (OA data with sample) - '30' (replicate sample)

Parameter 99105 (Replicate type) - `10' (concurrent)

Parameter 71999 (Sample purpose) - `15' (NAWQA)

SHIPPING

Samples should be shipped by overnight express mail to the NWQL the same day of collection. A NWQL ASR form must be included with each sample. Place all glass vials in padded sleeves or pack in

some other suitable manner to prevent breakage during shipment. Insulated water coolers (1 or 5 gal in volume) make good shipping containers. Chill with an adequate amount of ice to maintain the sample temperature between 0 and 4°C. The amount of ice needed depends on the length of time in transit from field to laboratory and on the season of the year. Ice should be placed inside a double plastic bag in the shipping container. Protect the NWQL ASR form and return labels from the ice by placing them in a sealable plastic bag and fastened it to the inside of the cooler lid with tape. Detailed guidelines on shipping samples are discussed in NWQL memorandum 95.04 (Appendix).

REFERENCES CITED

Brown, Eugene, Skougstad, M.W., and Fishman, M.J., 1970, Methods for collection and analyses of water samples for dissolved minerals and gases: U.S. Geological Survey Techniques of Water-Resources Investigations, book 5, chap. A1, 160 p.

Gilliom, R.J., Alley, W.M., and Gurtz, M.E., 1995, Design of the National Water-Quality Assessment Program: Occurrence and distribution of water-quality conditions: U.S. Geological Survey Circular 1112, 33 p.

Hirsch, R.M., Alley, W.M., and Wilber, W.G., 1988, Concepts for a National Water-Quality Assessment Program: U.S. Geological Survey Circular 1021, 42\x11p.

Kilpatrick, F.A., Rathbun, R.E., Yotsukura, N., Parker, G.W., and DeLong, L.L., 1989, Determination of stream reaeration coefficients by use of tracers: U.S. Geological Survey Techniques of Water-Resources Investigations, book 3, chap. A18, 52 p.

Koterba, M.T., Wilde, F.D., and Lapham, W.M., 1996, Ground-water data-collection protocols and procedures for the National Water-Quality Assessment Program: Collection and documentation of water-quality samples and related data: U.S. Geological Survey Open-File Report 95-399, 113 p.

Lopes, T.J., and Price, C.V., 1997, Study plan for urban stream indicator sites for the National Water-Quality Assessment Program: U.S. Geological Survey Open-File Report 97-25, 15 p.

Majewski, M.S. and Capel, P.D., 1995, Pesticides in the atmosphere: Distribution, trends, and governing factors: Chelsea, Mich., Ann Arbor Press, Pesticides in the Hydrologic System series, v. 1, 214 p.

Mueller, D.K., Martin, J.D., and Lopes, T.J., 1997, Quality-control design for surface-water sampling in the National Water-Quality Assessment Program: U.S. Geological Survey Open-File Report 97-223, 17 p.

Shelton, L.R., 1994, Field guide for collecting and processing stream-water samples for the National Water-Quality Assessment Program: U.S. Geological Survey Open-File Report 94-455, 42 p.

Shampine, W.J., Pope, L.M., and Koterba, M.T., 1992, Integrating quality assurance in project work plans of the U.S. Geological Survey: U.S. Geological Survey Open-File Report 92-162, 12 p.

Squillace, P.J. and Price, C.V., 1996, Urban land-use study plan for the National Water-Quality Assessment Program: U.S. Geological Survey Open File Report 96-217, 19 p.

Wilde, F.D., and Radtke, D.B., eds, in press, National field manual for collection of water-quality data, U.S. Geological Survey: Field measurements: U.S. Geological Survey Techniques of Water-Resources

Investigations, book 9, chap. A6, variously paged.

APPENDIX-SELECTED TECHNICAL MEMORANDUMS

These Water Resources Division (WRD) and National Water Quality Laboratory (NWQL) memorandums are available in U.S. Geological Survey offices, nationwide:

WRD 94.06 SAFETY: Storage, transport, handling, and disposal of hydrochloric acid

WRD 94.07 SAFETY: Storage, transport, handling and disposal of methyl alcohol

NWQL 95.04 OPERATIONS: Shipping to the National Water Quality Laboratory

Back to:

PNSP Publications
USGS Water Resources of California
NAWQA Program

For questions concerning this document, contact: <u>Larry Shelton</u> <lshelton@usgs.gov> The URL for this page is http://ca.water.usgs.gov/pnsp/pest.rep/voc.html">http://ca.water.usgs.gov/pnsp/pest.rep/voc.html">http://ca.water.usgs.gov/pnsp/pest.rep/voc.html